



Temperatuur en luchtvochtigheid

Temperatuur en luchtvochtigheid



DHT11



DHT11; van links naar rechts: *signaal* (naar port 2), *3.3V*, *GRND*.

Let op er zijn meerdere varianten en bij de meeste zit de data in het midden.

(<https://elektronicavoorjou.nl/product/dht11-temperatuur-en-vochtigheid-sensor/>)

Output

```
1
Temperature: 20.5 °C
Humidity:  45 %
2
Temperature: 20.5 °C
Humidity:  45 %
...
```

Code

```
#include <DHT.h>

#define DHTPIN 2      // Pin connected to the DHT11 data pin
#define DHTTYPE DHT11 // Specify DHT11 sensor

DHT dht(DHTPIN, DHTTYPE);
int count;

void setup() {
  Serial.begin(9600);
  dht.begin();
  count = 0;
  delay(5000);
}

void loop() {
  count++;
  delay(2000); // Wait 2 seconds between readings (DHT11 needs time)

  float temp = dht.readTemperature(); // Read temperature as a float
  int humidity = dht.readHumidity();

  if (isnan(temp)) {
```

```
Serial.println("Failed to read from DHT sensor!");  
} else {  
    Serial.println(count);  
  
    Serial.print("Temperature: ");  
    Serial.print(temp, 1);  
    Serial.println(" °C");  
  
    Serial.print("Humidity:  ");  
    Serial.print(humidity);  
    Serial.println(" %");  
  
    Serial.println("");  
}  
}
```

Revision #5

Created 11 March 2025 18:59:35 by Max

Updated 11 March 2025 19:28:01 by Max